



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

2003-07 Suzuki SV1000/1000S

Flange-On Exhaust System with DUAL Exhaust Canisters

Part # 005-1020406M / 005-1020407M / 005-1020408M / 005-1020419M / 005-1020420M



Parts List



Qty.	Description	Part Number
1	Flange-on Muffler Canister (Right Side)	Varies
1	Flange-on Muffler Canister (Left Side)	Varies
2	Muffler Canister Clamp	Varies
1	HARDWARE KIT	005-102-3
8	8mm Flat Washer	005-WF8
8	8x20mm Socket Head Cap Screw	005-SH820
2	TBR Script Logo Yellow Decal 4"	015-10208-A

IMPORTANT - PLEASE READ CAREFULLY

We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a centerstand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

Installation Instructions

1. Make sure the bike is completely cool before starting the installation. Make sure the bike is secure on a centerstand or ideally a service lift.
2. Remove the stock canisters at the passenger footpeg bracket and where they bolt to the end of the exhaust pipe. You will reuse the stock exhaust gaskets.
3. Install the new canisters, with the stock exhaust gaskets, onto the stock pipe flange using the 8mm x 20mm bolts and 8mm washers. Leave loose for now.
4. Carefully slide the canister clamp over the canisters. (Note: The stainless steel canister clamp and the name badge on the canister come from the factory with a clear plastic protective film. Please remove this film before operation.) Locate both tabs of the canister clamps on the outside of the passenger footpegs. Secure using the stock hardware.
5. Make sure everything is aligned and tighten all.
6. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters every 3,000 miles. Part #005-10038
Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



401 South Grand Ave., Santa Ana, CA 92705
Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

**2003-07 Suzuki
SV1000/1000S**

Flange-On Exhaust System with DUAL Exhaust Canisters
Part # 005-1020406M / 005-1020407M / 005-1020408M /
005-1020419M / 005-1020420M



005-1020406M



Qty.	Description	Part Number
1	Flange-on Muffler Canister (Right Side)	Varies
1	Flange-on Muffler Canister (Left Side)	Varies
2	Muffler Canister Clamp	Varies
1	HARDWARE KIT	005-102-3
8	8mm Flat Washer	005-WF8
8	8x20mm Socket Head Cap Screw	005-SH820
2	TBR Script Logo Yellow Decal 4"	015-10208-A

005-1020407M



Qty.	Description	Part Number
1	Flange-on Muffler Canister (Right Side)	Varies
1	Flange-on Muffler Canister (Left Side)	Varies
2	Muffler Canister Clamp	Varies
1	HARDWARE KIT	005-102-3
8	8mm Flat Washer	005-WF8
8	8x20mm Socket Head Cap Screw	005-SH820
2	TBR Script Logo Yellow Decal 4"	015-10208-A

005-1020408M



Qty.	Description	Part Number
1	Flange-on Muffler Canister (Right Side)	Varies
1	Flange-on Muffler Canister (Left Side)	Varies
2	Muffler Canister Clamp	Varies
1	HARDWARE KIT	005-102-3
8	8mm Flat Washer	005-WF8
8	8x20mm Socket Head Cap Screw	005-SH820
2	TBR Script Logo Yellow Decal 4"	015-10208-A

005-1020419M



Qty.	Description	Part Number
1	Flange-on Muffler Canister (Right Side)	Varies
1	Flange-on Muffler Canister (Left Side)	Varies
2	Muffler Canister Clamp	Varies
1	HARDWARE KIT	005-102-3
8	8mm Flat Washer	005-WF8
8	8x20mm Socket Head Cap Screw	005-SH820
2	TBR Script Logo Yellow Decal 4"	015-10208-A

005-1020420M



Qty.	Description	Part Number
1	Flange-on Muffler Canister (Right Side)	Varies
1	Flange-on Muffler Canister (Left Side)	Varies
2	Muffler Canister Clamp	Varies
1	HARDWARE KIT	005-102-3
8	8mm Flat Washer	005-WF8
8	8x20mm Socket Head Cap Screw	005-SH820
2	TBR Script Logo Yellow Decal 4"	015-10208-A